

# HONDA TCI

## - inductive ignition for HONDA motorbikes - detailed description

### 1. Hardware

HONDA TCI unit is produced in several versions for individual bike types:

- 1) Version for CBR, CBF, VT, VTR, XLV, NTV, VFR750.... (approx. 1990 ÷ 1999) – connector 16 pins
- 2) Version for CBR, CBF, VTR, XLV .... (approx. od r. 1997) – connector 22 pins

Software HONDA TCI.EXE is common for all version.

#### **Crankshaft position sensor CKPS.**

An input is ready for standard pickup sensors used on Honda motorbikes as CKPS.

#### **Revolution indicator output TACHO.**

The tachometer indicator output is compatible with major part of board devices used on Honda motorbikes (1 or 2 puls / rev.).

#### **NEUTRAL and SIDE STAND blocking inputs.**

In case at least one of these inputs is not grounded the unit locks ignition. Blocking feature can be switched off within HONDA TCI.EXE software.

#### **Induction coils IC 1, 4 and IC 2, 3.**

Induction coils outputs are ready for standard types, designed for inductive ignition and used on Honda motorbikes (primary coil resistance approx. 1 to 2 Ohm).

#### **Supply voltage +12 V.**

Nominal supply voltage is 14 V. It must be within 8 - 16 V range. In this range the unit is able to provide optimal control of all the processes. Ignition is stoped for supply voltage greater than 18.

#### **Connection to PC.**

Connection to PC is realized by 9-pin serial port (COM).

### 2. HONDA TCI software

#### **Pull down menus**

<b>File - includes items</b>	<b>New</b>	- default settings (serial adjustment)
	<b>Open</b>	- opens data file
	<b>Save</b>	- saves data file
	<b>Print</b>	- prints the current settings
	<b>Exit</b>	- exits the program

Warning!!! Clicking New results in automatic default settings of all parameters (serial adjustment) for the motorbike.

**Port - includes items**      **Com1 to Com10** - selection of communication line

<b>Device - includes items</b>	<b>Read</b>	- reads data from the unit
	<b>Verify</b>	- compares data in PC with data in the unit
	<b>Program</b>	- sends data to the unit and conducts verification

**Tools** – include items of collective settings

**Language** – language settings: **English, Czech, and German**

<b>Help</b> – includes items	<b>Help</b>	- opens assembly guide (this file)
	<b>About the program</b>	- data on the software (version, date)



- Default settings

Warning!!! Clicking this icon results in automatic default settings of all parameters



- opens data file



- saves data file



- prints the current settings



- see pull down menu **Device**

## Setting element

### 10 adjustable options for revolution/advance

Collective adjustment of the whole advance curve can be done by collective change tool (+ and – buttons with selection **All**)

When the motor is running current segment is highlighted in the advance curve. Use of collective change tool + and – button without selection **All** - just the current segment will be changed.

**Base advance** - here is necessary inscribe value of base advance (by figure 1)

**Limiter** - here is it possible to set maximal revolution.

**Tachometer 2x** - tachometer output settings

**Blocking enable** - enable or disable blocking by side stand.


**Programming after a change** - automatic programming settings (after every change)

**File:** - full path to currently opened file

### Pick-up system settings.

Ignition is designed for pick-up system on next figure. For in-line engines and V-engines with 30, 60 and 90° is dividing of noses by 30°. For V-engines with 52° is dividing by 26°.

Noses of pulse rotor are numbering 1 to 9. To field **TOP 1, 4** and to field **TOP 2, 3** you must inscribe number of nose bound to pick-up (at TOP position of several cylinder). For V-engines is 1, 4 rear cylinder and 2, 3 front cylinder.



Configuration for some motorbikes:

Motorbike	Cylinder 1, 4 (rear)	Cylinder 2, 3 (front)
CBR, CB	3	9
VF, XL125V, VTR	6	9
VT	8	9
NTV, XLV600,	4	9

## **Monitor**

Monitor is located on the right and lower side of the screen – sensor values and motor operational characteristics can be observed here. If there is **No connection with PC** displayed in the upper right corner, the unit is not connected or the Com is not proper set.

<b>RPM</b>	- engine revolution [1/min]
<b>U</b>	- supply voltage [V]
<b>ADVANCE</b>	- ignition advance [°]
<b>Blocking</b>	- activation signal of BLOCKING by side stand
<b>NEUTRAL</b>	- activation signal NEUTRAL
<b>SIDE STAND</b>	- activation signal SIDE STAND
<b>Number of programming</b>	- Number of times the unit has been programmed (applies only for Extended monitor option)